

Color Line Scan Camera Instruction Manual



Model: TLC-7300UCL



TAKENAKA SENSOR GROUP

TAKENAKA SYSTEM CO.,LTD.

- H e a d O f f i c e 86-66 Nomizo-cho Otsuka Yamashina-ku 607-8135 Kyoto JAPAN
TEL:+81-75-593-9300 FAX +81-75-593-9790
- C a m e r a D e p t . 4F Matsumasa Bld.1-17-14 Ogaya Otsu Shiga 520-2144 JAPAN
TEL:+81-77-545-4331 FAX +81-77-545-4335
- Inspection System Dept. 86-66 Nomizo-cho Otsuka Yamashina-ku 607-8135 Kyoto JAPAN
TEL:+81-75-593-9300 FAX +81-75-593-9790
- T o k y o O f f i c e 2F MK Bldg. 2-2-19 Sotokanda Chiyoda-ku 101-0021 Tokyo JAPAN
TEL :+81-3-3255-0361 FAX:+81-3-3255-0362

TAKENAKA SYSTEM CO.,LTD.
TAKENAKA SENSOR GROUP

URL <http://www.takex-system.co.jp/>
URL <http://www.takex.co.jp/>

The Brief History of Takenaka System Co.

Takenaka System Co.(Trade mark:TAKEX) is the Japan's first company to have produced the Line scan cameras. It was established in 1975 and began to produce and sell the Line scan cameras that year. And then, Takenaka System Co. is continuing to produce high quality line scan cameras such as C-MOS/ CCD Line scan cameras, CCD Analog line scan cameras, CCD Digital line scan cameras and CCD Camera Link line scan cameras, as a pioneering company in the Japanese industry,. Also, Takenaka System Co. began to produce the compact CCD video cameras since 1983, and is a first producer of Progressive scan cameras for industrial use in Japan. We think it is a mission of our company to continue to provide the high-quality Line scan cameras and Progressive scan cameras to the industry as image input device for image processing apparatus. We are confident that the Takenaka's products that met the strict delivery criteria are assured of trouble-free operation over a long period of time.

Table of Contents

1. Outline	4
2. Features	4
3. CCD image sensor	4
4. Specifications	5
5. Camera I/O	5
6. Connection Diagram	7
7. Initial setting	8
7-1 Operational setting of the camera	
7-2 White balance setting	
7-3 FFC Function setting	
7-4 Analog gain control	
7-5 Color gap correction	
7-6 Data rate setting	
8. Exposure Control	14
9. Timing Chart	16
10. Serial Communication Protocol	18
11. Setup Steps of Hyper Terminal	25
12. Notes	26
13. External Dimensions	27

1. Outline

TLC-7300UCL is the color line scan camera with 3-lines (RGB) of 7300-pixels CCD image sensor and has the following features.


2. Features

- Capable of performing high-resolution inspection with 7300-pixels CCD image sensor.
- The pixel size is large enough ($10\mu\text{m}\times 10\mu\text{m}$) to capture high S/N images
- The high speed operation at 120MHz data rate (Medium configuration mode) and 80MHz data rate (Base configuration mode).
- Simplified shutter function allows the shutter to operate at 7kHz scan rate in Medium configuration mode.
- Possible to configure various camera settings by means of serial communication via capture board.
- Equipped with Color gap correction function.
- Equipped with FFC function.
- Equipped with White balance function.
- The equipment operates with a single DC12V power source.
- Possible to get stable video signal despite a change of ambient temperature, as the dark current correction circuit is incorporated.
- Reduction in size and weight has been realized by original design


3. CCD image sensor

Equipped with High-sensitive and high-speed CCD sensor with 7,300 effective pixels, of which pixel size is $10\mu\text{m}$ square. Charges accumulated in single-row photo diodes are output through ODD and EVEN analog shift registers respectively. Quad parallel shift registers make it possible to increase transfer efficiency and to obtain high-quality images. CCD transfer frequency is 30MHz.

Block diagram of CCD device



Sensitivity-Wavelength Characteristics




4. Specifications

Number of pixels	7300 × 3 lines	
Unit cell size	10μ m × 10μ m	
Photo array length	73mm	
Video output (Digital output)	8Bit Base Configuration	8Bit Medium Configuration
Video rate	80MHz (RGB) each	60MHz × 2 (RGB) each
Scan rate (scan/sec)	10KHz	15KHz
Line transfer pulse input	100μsec (Min)	66μsec (Min)
Sensitivity	50 V/lx. sec (at Gain setting:1)	
Saturated exposure amount	0.19 lx. sec (on the element)	
Output uniformity	10% standard at 50% of saturation output (on the element)	
Dynamic range	250 (on the element)	
Flange focus	28.8 mm	
Power supply	+12V ±0.5V (1.5A or less)	
Operational ambient temperature	0 ~ +40°C	
Operational humidity range	85% MAX	
Storage temperature range	-10°C ~ +65°C	
Weight	720g or less	
External dimension (mm)	108(W) × 110(H) × 55.5(D)	
lens mount	M 80, P = 0.75 mm	

5. Camera I / O


5-1 Signal I/O

The line scan camera is connected to the Frame grabber with two Camera Link cables.



5-2 Camera Link connector

Camera Link connector pin-out



Signal name	Connection
CC1	EXSYNC
CC2	Spare
CC3	Spare
CC4	Spare

Base Configuration Connector

Pin No.	Signal name	Pin No.	Signal name
1	Shield	14	Shield
2	X0-	15	X0+
3	X1-	16	X1+
4	X2-	17	X2+
5	Xclk-	18	Xclk+
6	X3-	19	X3+
7	Ser TC+	20	Ser TC-
8	Ser TFG-	21	Ser TFG+
9	CC1-	22	CC1+
10	CC2+	23	CC2-
11	CC3-	24	CC3+
12	CC4+	25	CC4-
13	Shield	26	Shield

Medium Configuration Connector

Pin No.	Signal name	Pin No.	Signal name
1	Shield	14	Shield
2	Y0-	15	Y0+
3	Y1-	16	Y1+
4	Y2-	17	Y2+
5	Yclk-	18	Yclk+
6	Y3-	19	Y3+
7	100Ω	20	terminated
8	Z0-	21	Z0+
9	Z1-	22	Z1+
10	Z2-	23	Z2+
11	Zclk-	24	Zclk+
12	Z3-	25	Z3+
13	Shield	26	Shield

5-3 Bit assignment

Base 8 Bit : 1~7300 pixel
Medium 8 Bit : 1~3650 pixel

Unused
7300~3651 pixel


Base connector			
Port/bit	8-bit	Port/bit	8-bit
Port A0	R0	Port B4	G4
Port A1	R1	Port B5	G5
Port A2	R2	Port B6	G6
Port A3	R3	Port B7	G7
Port A4	R4	Port C0	B0
Port A5	R5	Port C1	B1
Port A6	R6	Port C2	B2
Port A7	R7	Port C3	B3
Port B0	G0	Port C4	B4
Port B1	G1	Port C5	B5
Port B2	G2	Port C6	B6
Port B3	G3	Port C7	B7

Medium connector			
Port/bit	8-bit	Port/bit	8-bit
Port D0	R0	Port E4	G4
Port D1	R1	Port E5	G5
Port D2	R2	Port E6	G6
Port D3	R3	Port E7	G7
Port D4	R4	Port F0	B0
Port D5	R5	Port F1	B1
Port D6	R6	Port F2	B2
Port D7	R7	Port F3	B3
Port E0	G0	Port F4	B4
Port E1	G1	Port F5	B5
Port E2	G2	Port F6	B6
Port E3	G3	Port F7	B7

5-4 Power connector


Power connector pin assignment

Pin No.	Signal name	Pin No.	Signal name
1	+ 1.2 V	4	GND
2	+ 1.2 V	5	GND
3	+ 1.2 V	6	GND



Conforming connector
HR 10A-7R-6PB

6. Connection Diagram




7. Initial setting

The following settings can all be made by communication command of Hyper terminal (See P.20-22).
Make the setting according to TLC-7300UCL_RS232C communication protocol (P.18-19)

At Hyper terminal

Command

cfg <CR> To get the internal settings of the camera.



```

cfg
ver=2.2.9 rev=8 id=0
sync=0 scan_dir=0
expc=0 expt=3 explt=39 [807]
offset=0,0,0,0,0,0,0,0,0,0,0,0
testp=0 lval=0 lv_st=0 _end=0
rgb_on=1 _dir=0 _ldelay=2 _ld2=4
shade=0 shd_go=1 _ch=1 _ul=1
shd_ad=0/0[0] _dat=0/0[0] _tg=200 _to=3
wlc0=64 wlc1=2 speed=0
pwb_tg=180 pwb_mask_a=0 pwb_mask_b=0 gainpos=1
gain1=0,0,0,0,0,0,0,0,0,0,0,0
gain2=45,45,45,45,45,45,45,45,45,45,45,45

```

7-1 Operational setting of the camera

7-1-1 Synchronization setting

Sync=N <CR>

To set the camera SYNC mode.

0: Auto mode (Ext/Int Sync)

1: Ext Sync (External synchronization)

2: Int Sync (Internal synchronization)

3: Ext Sync & Anti Blooming (External synchronization)

7-1-2 Exposure mode setting

expc= N <CR>

To set the Exposure control mode.

0: Line period exposure

1: Fixed time exposure (value of expt & explt)

2: Pulse width exposure

(Refer to Exposure control for the detail)

expt= A <CR>

To set the Exposure time of the camera (in 256 clks).

explt= B <CR>

To set the Exposure time of the camera (in clk).

A=0 to 255 B=0 to 255

Exposure time : $\text{expt} \times 256 + \text{explt} [\text{clk}]$ (1clk=33.33ns)


80MHz mode minimum value $\text{expt}=3$, $\text{explt}=39$

※ "expc = 1" is disabled when "sync=0".

※ "expc = 0" is disabled when "sync=3".

7-2 White balance setting

This is the function to adjust ODD/EVEN levels and to achieve white balance.
White balance should be adjusted before executing FFC function.



<Setup steps>

The gain position can be specified in white balance setting.
The gain values are set in the specified gain position.

- `pwb_tg=0` <CR> To set the analog gains of all RGB channels to minimum.
Minimum value = 1
- `pwb_set` <CR> To achieve a white balance .
- `pwb_tg=N` <CR> To set the target level of white balance.
Default value =180 N : 0 to 255

Take a defocused image of a surface of a plain white paper.
Check if it is not fogged by halation for each RGB line.
Use the stable illumination light source.

- `pwb_set` <CR> To start to achieve a white balance.
Completed when “OK” is displayed.
- `save` <CR> To save the settings into EEPROM.
Completed when “OK” is displayed.

<Confirmation of settings>

- `cfg` <CR> To get the internal settings of the camera.

```
pwb_tg=180 pwb_mask_a=0 pwb_mask_b=0 gainpos=1
gain1=0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0
gain2=45,45,45,45,45,45,45,45,45,45,45,45,45,45,45,45
```

↑ Settings before achieving a white balance.
Settings in gain position1 will be changed in this case.

White balance is achieved according to the above <Setup steps>.


- `cfg` <CR> To get the internal settings of the camera.

↓ Check if the gain values in the specified gain position has been definitely changed.

```
pwb_tg=180 pwb_mask_a=0 pwb_mask_b=0 gainpos=1
gain1=195,193,194,190,151,157,153,163,219,219,217,217,217,217,217,217
gain2=45,45,45,45,45,45,45,45,45,45,45,45,45,45,45,45
```

7-3 FFC Function setting

Flat field correction (also called Shading Correction) is a function used to compensate for shading of an image signal arising from imperfections or inhomogeneities of lens or picture/filter elements .



◆ Light level (shd-tg) setting 8bit

◆ Dark level (shd-to) setting 8bit

<Setup steps>

1. Dark level correction

shade=0 <CR>	To turn the FFC function off. To reset the shading gain value stored in the camera.
shade=4 <CR>	To permit to enter the shading data.
shd_go=1 <CR>	To select the shading gain setting mode
shd_dat=0 <CR>	To enter "0" as the shading gain value
shd_set <CR>	To set the shading data.
shd_to=N <CR>	To set the target Dark level. Default value = 3 N : 0 to 255

Then put a cap over a lens.

shade = 6 <CR>	To start the shading correction for Dark level signal. Completed when "OK" is displayed.
----------------	---

2. Light level correction

Remove a lens cap and set the target gray level of video signal level.
Take a defocused image of a surface of a plain white paper.
Make the signal level adjustment by changing lens aperture or exposure time.
(Note: Make sure a foreign object does not exist within the visual field.)

shd_tg=N <CR>	To set the target Light level. Default value =150 N : 0 to 255 (Set the target Light level to the level that is higher than the signal level before Light level correction.)
shade = 5 <CR>	To start the shading correction for Light level signal. Completed when "OK" is displayed. Then, a flat gray image is obtained.
shd_epsv <CR>	To save all shading correction values into EEPROM. Completed when "OK" is displayed.
shade=1 <CR>	To turn the shading correction function on.
save <CR>	To save the system settings into EEPROM. Completed when "OK" is displayed.

3. Confirmation of shading data

Each pixel data are output as a video output by configuring the settings below

Confirmation of shading gain value

1. shd_go=1 <CR> To select the shading gain setting mode(Light level coefficient)
2. shade=2 <CR> To permit to output the shading data.
3. shd_ul=N <CR> Upper /lower bit switching. N: 0(upper 8bit) or 1(lower 4bit).
4. Shading gain values of each pixel are output as video output.

Confirmation of shading offset value

1. shd_go=2 <CR> To select the shading offset setting mode(Dark level coefficient)
2. shade=2 <CR> To permit to output the shading data
3. shd_ul=N <CR> Upper /lower bit switching. N: 0(upper 8bit) or 1(lower 4bit).
4. Shading offset values of each pixel are output as video output.

4. Direct entry of shading data

Entry of shading gain value


1. shd_go=1 <CR> To select the shading gain setting mode(Light level coefficient)
2. shade=3 <CR> To permit to input the shading data
3. shd_ad1=M <CR> To enter the pixel address
shd_ad0=N <CR> pixel address: $M \times 256 + N$
Pixel address starts from 0.
4. shd_dat=N <CR> To enter the upper 8bit data. N: 0 to 255.
5. shd_dat1=N <CR> To enter the lower 4bit data. N: 16 to 240.
6. shd_set <CR> To enter the shading data.
7. Repeat step 3 to 6 when entering the shading data of another pixel.
8. shade=1 <CR> To turn FFC function(Shading function) ON.

Entry of shading offset value

1. shd_go=2 <CR> To select the shading offset setting mode(Dark level coefficient)
2. shade=3 <CR> To permit to input the shading data
3. shd_ad1=M <CR> To enter the pixel address
shd_ad0=N <CR> pixel address: $M \times 256 + N$
Pixel address starts from 0.
4. shd_dat=N <CR> To enter the upper 8bit data. N: 0 to 255.
5. shd_dat1=N <CR> To enter the lower 4bit data. N: 16 to 240.
6. shd_set <CR> To enter the shading data.
7. Repeat step 3 to 6 when entering the shading data of another pixel.
8. shade=1 <CR> To turn FFC function(Shading function) on.

7-4 Analog gain control

This is the function to adjust an analog gain by setting a total of 12 channels (Red 4, Green 4, Blue 4). Two sets of analog gain values can be stored in two gain positions.



<Setup steps>

chXgainA = N

<CR>


To specify the channel to change the analog gain.

Gain channel X = 1 to 12

Gain position A = 1, 2

Gain adjustment range N = 0 to 1023

$$\text{Analog Gain} = -6 \text{ dB} + 0.04 \text{ dB} \times N$$



7-5 Color gap control

This is the function to correct the color gap by delaying the output timing of two lines (Red□Green or Green□Blue).

<Setup steps>

rgb_on = 1	<CR>	To enable color gap correction. 0 : OFF 1 : ON
rgb_dir = 0	<CR>	To select a direction for correction. 0 : R → G → B 1 : B → G → R
rgb_ldelay = N	<CR>	To set the correction amount (line numbers) for the second line. N = 0 to 8
rgb_ld2 = N	<CR>	To set the correction amount (line numbers) for the third line. N = 0 to 8

Example: rgb_dir = 0 and the delay amount between adjacent lines is 2 lines.

```

rgb_ldelay = 2 & rgb_ld2=4
  Red delay lines   : 4 lines  (rgb_ld2)
  Green delay line  : 2 lines  (rgb_ldelay)
  Blue delay lines  : 0 line

```

7-6 Data rate setting

This is the function to switch the video output mode between "80MHz Base Configuration" and "120MHz Medium Configuration".

<Setup steps>

1. The data rate 80MHz [Base Configuration] mode.

```

scan_dir = 2    <CR>
speed = 1       <CR>

```

2. Data rate 120MHz [Medium Configuration] mode

```

scan_dir = 0    <CR>
speed = 0       <CR>


```

8. Exposure Control


TLC-7300UCL External SYNC (sync=1)

Line period exposure (sync=1, expc=0)


Exposure during each period of EXT. SYNC(CC1)

**Fixed time exposure**(sync=1, expc=1, expt=N, explt=A) (sync=3, expc=1, expt=N, explt=A)

Exposure during the period of the equation below from the timing of leading edge of EXT. SYNC(CC1).

Exposure time = $66.7 + (N \times 256 + A) 0.033$ (μsec)Minimum exposure time = $66.7 \mu\text{sec}$ * Note that the minimum period of EXT. SYNC is $133.4 \mu\text{sec}$ inMinimum period = $66.7 \mu\text{sec} + \text{DATA output duration}(66.7 \mu\text{sec})$ **Pulse width exposure** (sync=1, expc=2) (sync=3, expc=2)

Exposure during the period of the pulse width of EXT. SYNC(CC1).


Minimum exposure time = $66.7 \mu\text{sec}$ * Note that the minimum period of EXT. SYNC is $133.4 \mu\text{sec}$ in the Pulse width exposure mode.Minimum period = $66.7 \mu\text{sec} + \text{DATA output duration}(66.7 \mu\text{sec})$ 

TLC-7300UCL Internal SYNC (sync=2)


Line period exposure (sync=1, expc=0)

Exposure during each period of EXT. SYNC(CCI)


The line period is decided by the value of expt and explt.



9. Timing Chart



TLC-7300UCL 80MHz Base Configuration Mode Timing Chart



10. Serial Communication Protocol

[Network transmission setting]

Baud rate	:9600bps
Data Length	:8bit
Start Bit	:1bit
Stop Bit	:1bit
Parity	:Non
Xon / Xoff Control	:Non

[Communication overall]

1. Referring

To refer to the status of the camera.

e.g. Id? <CR> To refer to the camera ID.

2. Setting

To set the status of the camera.

e.g. sync=1 <CR> To set SYNC system to EXT.SYNC

[Glossary]

[]omissible
<CR>carriage return
Narbitrary numeral indicating some value
Aarbitrary numeral indicating GAIN position
Xarbitrary numeral indicating Channel
Gain position.....	GAIN position of the camera
ChannelChannel to specify the GAIN control device for each CCD output line
EEPROMEEPROM incorporated in the camera

[Notes]

- Command name must be lower-case. Upper-case character is not valid.
- Input character must be one-byte character. Double-byte character is not valid.
- Blank is not valid.
- Line feed code is indicated by “CR(0x0D)”. And also “LF(0x0A)” and “CR+LF” are usable. However returning line feed code must be CR only.

<When using Hyper terminal>

- Retyping is required In case of inputting error.(Correction by cursor movement is not valid.)

[Description of exceptional case]

* NG is returned in case of command input error or inputting nonexistent command.

e.g. : Command input error (Gain position No. is not designated.)

Input: ch1gain=96

Output: NG

e.g. : Input of nonexistent command

Input: chake

Output: NG

* NE is returned in case of numeric entry error.

e.g. : Input error (Input value is beyond the setting range.)

Input: gainpos=96

Output: NE

e.g. : Input error (Input value is beyond the setting range.)

Input: ch1gain1=2000

Output: NE

* NC is returned in case of inputting invalid value under the condition that the ctrl setting (DIP-SW setting) is 0.

e.g. :

Input: ch1gain=96 (at ctrl=0)

Output: NC

* TO is returned when a command input period overruns the time-out period (15 sec.).

e.g. :

Input: gainpo (No CR entry)

Output: TO

* " ? " at the bottom of Command is omissible

e.g. :

Input: id

Output: 0

	Command Name	Format	Argument	Return value	Explanation
User	Get ID *1	id[?]<CR>	Non	ID(Default: 0)	Get the camera ID This is for multiple camera management
	Set ID *1	id=N<CR>	N: 0~255	OK	Set the camera ID This is for multiple camera management
Sync selection	Get Sync.	sync[?]<CR>	Non	0: Auto mode 1: Ext Sync 2: Int Sync 3: Ext Sync(AntiBlooming)	Get the Sync system of the camera
	Set Sync.	sync=N<CR>	N=0: Auto mode N=1: Ext Sync N=2: Int Sync N=3: Ext Sync(AntiBlooming)	OK	Set the Sync system of the camera Ext Sync is from CC1.
Exposure control	Get Exposure Control	expc[?]<CR>	Non	0: Line period exposure 1: Fixed time exposure 2: Pulse width exposure	Get the Exposure control status
	Set Exposure Control	expc=N<CR>	N=0: Line period exposure N=1: Fixed time exposure N=2: Pulse width exposure	OK	Set the Exposure control status
Exposure time	Get Exposure Time	expt[?]<CR> explt[?]<CR>	Non	0-255: Exposure time	Set the Exposure time
	Set Exposure Time	expt=N<CR> explt=N<CR>	N=0-255: Exposure time	OK	Get the Exposure time
Gain	Get Gain Position	gainpos[?]<CR>	Non	1-2: Gain position	Get the Gain position
	Set Gain Position	gainpos=A<CR>	A=1-2: Gain position	OK	Set the Gain position
	Get chXgainA	chXgainA[?]<CR>	X=1-12: ch A=1-2: Gain position	0-255: Gain level	Get the Gain level of each gain postion of each channel
	Set chXgainA	chXgainA=N<CR>	X=1-12: ch A=1-2: Gain position N=0-255: Gain level	OK	Set the Gain level of each gain postion of each channel
Color Gap	Color gap control on/off	rgb_on=N<CR>	0: OFF 1: ON	OK	Color gap control on/off value setting
		rgb_on[?]<CR>	Non	0: OFF 1: ON	Color gap control on/off value reference
	Color gap dir	rgb_dir=N<CR>	0: RGB 1: BGR	OK	Color gap scan direction value setting
		rgb_dir[?]<CR>	Non	0: RGB 1: BGR	Color gap scan direction value reference
	Color gap line	rgb_ldelay=N<CR>	N: 0-8	OK	Color gap delay lines value setting
		rgb_ld2=N<CR>	N: 0-16	OK	Color gap delay lines value setting
		rgb_ldelay[?]<CR>	Non	0-8	Color gap delay lines value reference
		rgb_ld2[?]<CR>	0-16	OK	Color gap delay lines value reference
System	Check	check<CR>	Non	OK	Communication test
	Save	save<CR>	Non	OK	Save settings to the EEPROM
	Load	load<CR>	Non	OK	Load settings from the EEPROM
	Version	ver<CR>	Non	Version	Get the version number of the program for the microcomputer control
	Revision	rev<CR>	Non	Revision	Get the version number of FPGA
	Initialize	init<CR>	Non	OK	Load the factory settings
	config	cfg<CR>	Non	(Data output)	Get the all current settings

*1...ID can be saved on the user area of the EEPROM by the save command. It cannot be cleared by the clear command.

	Command Name	Format	Argument	Return value	Explanation
SHADE	Shade Control Mode	shade=N<CR>	0:OFF 1:ON 2:Data out 3:Data in 4:Data all in 5:Auto shade for gain 6:Auto shade for offset	OK	Shade control mode Getting/setting
		shade[?]<CR>	Non	0:OFF 1:ON 2:Data out 3:Data in 4:Data all in 5:Auto shade for gain 6:Auto shade for offset	
	shade=2 output data bit	shd_ul=N<CR>	N=0 or 1	OK	Setting shade=2 output data bit 0:FFC coefficients upper 8bit 1:FFC coefficients lower 4bit
	Gain/Offset	shd_go=N<CR>	0:OFF 1:Gain 2:Offset	OK	Target value Getting/setting
		shd_go[?]<CR>	Non	0:OFF 1:Gain 2:Offset	
	Pixel Address (Lower)	shd_ad0=N<CR>	N:0-255	OK	Correction targeted pixel (The lower address)
		shd_ad0[?]<CR>	Non	0-255	Getting/setting
	Pixel Address (Upper)	shd_ad1=N<CR>	N:0-255	OK	Correction targeted pixel (The upper address)
		shd_ad1[?]<CR>	Non	0-255	Getting/setting (Note.1)
	Value set (Lower)	shd_dat0=N<CR>	N:0-255	OK	Data value setting(The lower data) Getting/setting
		shd_dat0[?]<CR>	Non	0-255	
	Value set (Upper)	shd_dat1=N<CR>	N:0-255	OK	Data value setting(The upper data) Getting/setting (Note.2)
		shd_dat1[?]<CR>	Non	0-255	
	Taget Level for black level	shd_to=N<CR>	N:0-255	OK	Correction targeted level Getting/setting for black level.
		shd_to[?]<CR>	Non	0-255	
	Taget Level for gray level	shd_tg=N<CR>	N:0-255	OK	Correction targeted level Getting/setting for gray level.
		shd_tg[?]<CR>	Non	0-255	
	Data set	shd_set<CR>	Non	OK	Data set
	EEPROM load	shd_epld<CR>	Non	OK	EEPROM all load
	EEPROM save	shd_epsv<CR>	Non	OK	EEPROM all save
	EEPROM clear	shd_epcl<CR>	Non	OK	EEPROM all clear
White balance	Taget Level for level	pwb_tg=N<CR>	N:0-255	OK	Correction targeted level
		pwb_tg[?]<CR>	Non	0-255	
	pwb_execute	pwb_set<CR>	Non	OK	White balance
OUT PUT MODE	Base Configurion Mode	scan_dir=2<CR>	N:0or2	OK	80Mhz data rate mode.
		speed=1<CR>	N:0or1	OK	(Base Configuration)
	Medium Configurion Mode	scan_dir=0<CR>	N:0or2	OK	120Mhz data rate mode.
		speed=0<CR>	N:0or1	OK	(Medium Configuration)

(Note.1) Pixel address = B × 256 + A

:shd_ad0=A shd_ad1=B

(Note.2) Pixel data = D × 256 + C

:shd_dat0=A shd_dat1=D

shd_dat0=0 shd_dat1=0 right edge.

	Command Name	Format	Argument	Return value	Explanation
White balance	Taget Level for pwb	pwb_tg=N<CR>	N:0-255	OK	Correction targeted level
		pwb_tg[?]<CR>	Non	0-255	
	Mask channel for pwb	pwb_mask_a=N<CR>	N:0-255	OK	The channel not corrected is set. _a lower 4bit : Red _a upper 4bit : Green _b lower 4bit : Blue
		pwb_mask_b=N<CR>	N:0-255	OK	
		pwb_mask_a[?]<CR>	Non	0-255	
		pwb_mask_b[?]<CR>	Non	0-255	
	pwb_execute	pwb_set<CR>	Non	OK	White balance
LVAL Control	LVAL control on/off	lval=N<CR>	0:OFF 1:ON	OK	LVAL control on/off value reference/setting
		lval[?]<CR>	Non	0:OFF 1:ON	
	LVAL start timing	lv_st=N<CR>	0-255	OK	LVAL start timing value reference/setting
		lv_st[?]<CR>	Non	0-255	
	LVAL end timing	lv_end=N<CR>	0-255	OK	LVAL end timing value reference/setting
		lv_end[?]<CR>	Non	0-255	
OUT PUT MODE	Base Configuration Mode	scan_dir=2<CR>	N:0or2	OK	80Mhz data rate mode. (Base Configuration)
		speed=1<CR>	N:0or1	OK	
	Medium Configuration Mode	scan_dir=0<CR>	N:0or2	OK	120Mhz data rate mode. (Medium Configuration)
		speed=0<CR>	N:0or1	OK	


11. Setup Steps of Hyper Terminal

[Setup of Hyper terminal] (In case of Microsoft Windows2000,WindowsXP)

- 1) Select “Start”→“Programs”→”Accessories”→”Communications”→”Hyper Terminal”
- 2) The windows will appear with the picture below.




- 3) When the next picture appears, enter any name.(e.g. GMA_RS232C) Then click the “OK” button.



- 4) When the next picture appears, select “ COM? ” on Connect using. (COM? changes depending on PC or capture board.) Then click the “OK” button.




- 5) When the next picture appears, select each items as follows.(9600,8,None,1,Non) Then click the “OK” button.




[Network transmission setting]

Baud rate	:	9600 bps
Data length	:	8 bit
Start bit	:	1 bit
Stop bit	:	1 bit
Parity	:	Non
Xon / Xoff control	:	Non


6) The next picture will appear.




7) Select [File]→[Properties]




8) Select “Settings” tag.



9) Click the “ASCII Setup” button.




- 10) When the next picture appears, select each items as follows.(☑, ☑, 0, 0,☑, blank, blank)
Then click the “OK” button.



- 11) The screen display will return to the screen of paragraph 9.
Then click the OK button.

- 12) End of setup.

Confirm the connection of the camera, then enter “check” on the screen below and send it out.
If “OK” is displayed on the screen, communication processing has been completed.



※ When using WindowsXP(64bit), it may come to “NG” right after “OK” is displayed.
In that case, uncheck the “Send line ends with line feeds” checkbox of above paragraph 10.

- 13) Select “Start”→“Programs”→“Accessories”→“Communications”→“Hyper Terminal” →“(* 1)”, when
to launch the Hyper terminal again with the same settings after having exited the above screen.

* 1.....The name which was entered at paragraph 3.

12. Notes

- If dust sticks to the protective glass of CCD image sensor, image signal cannot be output from the photo diodes on this part and it exhibits symptoms similar to defect pixels.
In this case, blow away dusts with an air spray. However, note that water droplet may be sprayed out from an air spray.
- Do not store the equipment in extremely hot places where is subjected to direct sunlight.
- Do not remove a cover and do not insert/remove a Camera Link connector when applying current to the equipment. It causes the equipment to malfunction.
- Use a ceramic driver to adjust ODD/EVEN video signal.
- When disposing of the equipment, delegate the task to the industrial waste disposal contractor. And execute the disposing procedure following related laws and regulations.
- Do not use the equipment in an environment subject to intense electromagnetic or electrostatic field. Also, if the earth connection is imperfect, the image signal may contains inductive noise components and it causes the equipment to malfunction.

13. External Dimensions

